

Cleaning Combi Electrodes (probes)



**Remove cover over steam chamber
to view water level electrodes**



**Carefully slide wire connectors off electrodes
Pull electrode up and out.
Immerse probe in mild decalcifying agent (i.e. CLR)
for a period of time.
Wipe clean and rinse thoroughly.**

**Re-insert electrode back into position
Re-connect electrodes according to
corresponding color**