

SAUNA CRAFT HI LIMIT ADJUSTMENT AND REPLACEMENT

WARNING: Before working on the sauna heater, ensure the breaker is turned off. Test connections with meter to confirm power is disconnected.



Unscrew Hi-Limit from frame



Remove lock washer and shield



Remove wire leads. Replace hi-limit. Reconnect hi-limit.

**** Important:**

Re-install plastic shield and lock washer.

(A socket nut driver is useful to re-secure lock washer.)



Occasionally, hi-limits cause “nuisance tripping”. It may be caused by insufficient airflow or by retained heat in metal frame passing to the hi-limit. One way to address this is to place the hi-limit sensor through the back hole of the junction box and leave it suspended in air behind the heater.