

- Sauna heaters
- Sauna Material Liner Kits
- Pre-Fab Saunas
- Infrared Saunas
- Steambath Generators

Tylo Hi-Limit Reset

When high limit trips:

- Heaters with built controls: Timer will still tick (mechanical), but there will be no output.
- Heaters with electronic controls: Control will be blank if heater high limit trips.

Therm-O-Disc Type (White Stem)

All Current "Sense" Model (and older Sport/SuperSport 7&8)

Limit is on left side of junction box



When tripped, stem is pushed out.



Capillary Type (Red Button)

Older model Tylo Heaters (and current Deluxe 11)

Heaters with this type of limit may have one, two or three hi-limits. Located on back side near bottom.

Sport/SuperSport 2/4 has one.

Deluxe 7&8 and SE 7&8 models have two (as pictured below)

Deluxe 11 & Deluxe 16 have three

Combi 7&8 has one (for steam portion)

In normal operation, the red button will feel spongy or springy. It will bounce out if pressed. When the hi-limit has tripped, the button will be rigid. Give it a hard push. It will click in and become springy again.

