


**EL-13-R CONTROL WITH EXTERNAL SWITCH**

**NOTE:** EL-13-R is special order. You cannot add external switch to standard control. Wiring shown is just for external switch. See separate control/heater diagrams.

**INSTALL OUTSIDE OF SAUNA**

Connect control to external start/stop switch (included) (wire not included).

Install external switch in one-gang box (not included).

Run 18/3 from switch to control.

Wire can 200-300 hundred feet. Do NOT run low voltage wire next to line voltage.

Button will switch sauna on & off

The LED light will come on when sauna is operating. It will go off when sauna is off.

(Will not connect wirelessly via Alexa, Google Home or similar).

