
## **EL-13-R CONTROL** with External Switch

## **NOTE:**

EL-13-R is special order. You cannot add external switch to standard control. Wiring shown is just for external switch. See separate control/heater diagrams.

## **INSTALL OUTSIDE OF SAUNA**



Connect control to external start/stop switch (included). (wire not included)

Install external switch in one-gang box (not included). Run 18/3 from switch to control.

Wire can 200-300 hundred feet. Do NOT run low voltage wire next to line voltage.

Button will switch switch sauna on & off.

The LED light will come on while sauna is operating. It will go off when sauna is off.

(Will not connect wirelessly via Alexa, Google Home or similar)

