Operating instructions for Homecraft touchpad



- 1. When the sauna is "off," the display will read "off."
- 2. Press the Power button to automatically turn the sauna on.
- 3. Press the F/C button to choose to display the temperature in Fahrenheit or Celsius.
- 4. The default setting is 90C / 194F and pre-set to 60 minutes.
- 5. To change the temperature or time, simply hold the Up/Down arrow down for 3 seconds to increase or decrease the temperature or time as desired.
- 6. The LED display will show the room temperature when it is on.
- 7. To display the current "set" temperature, momentarily press the temperature button. The "Set" temperature will display for 3 seconds.
- 8. To display the remaining time, momentarily press the time button. The remaining time will display for 3 seconds.