

WARNING

Before working on the sauna heater, ensure the breaker is turned off.
Test connections with meter to confirm power is disconnected.



Unscrew Hi-Limit from frame



Remove lock washer and shield



**Remove wire leads. Replace hi-limit.
Reconnect hi-limit.**

Important: Re-install plastic shield and lock washer.
(A socket nut driver is useful to re-secure lock washer.)