

Commercial: 208volt, 3 Phase Wiring

(Magnetic contactor to be fird isntalled between breaker and sauna. Usually isntalled near breaker or in access box)

(TPT3 (mechanical))

(EL13 (electronic))

Ensure that correct voltage is applied to the contactor coil.

— Control Wire (#14)
 — Supply Wire
 - - - Dashed line for 3 Phase Only

Sensing bulb comes connected to control. Remove and relocate. Sensing bulb should be located at ceiling 1'-2' from heater, 1" maximum from ceiling
 12' of capillary wire included. (If additional length required, use 18ga or 20ga wire to extend)

