

- Sauna heaters
- Sauna Material Liner Kits
- Pre-Fab Saunas
- Infrared Saunas
- Steambath Generators

# Tylo Hi-Limit Reset

## When high limit trips:

- Heaters with built controls: Timer will still tick (mechanical), but there will be no output.
- Heaters with electronic controls: Control will be blank if heater high limit trips.

## Therm-O-Disc Type (White Stem)

### All Current "Sense" Model and older Sport and SuperSport

Limit is on left side of junction box



When tripped, stem is pushed out.



## Capillary Type (Red Button)

### Older model Tylo Heaters (and current Deluxe 11)

Heaters with this type of limit may have one, two or three hi-limits. Located on back side near bottom.

Deluxe 7&8 and SE 7&8 models have two (as pictured below)

Deluxe 11 & Deluxe 16 have three

Combi 7&8 has one (for steam portion)

In normal operation, the red button will feel spongy or springy. It will bounce out if pressed. When the hi-limit has tripped, the button will be rigid. Give it a hard push. It will click in and become springy again.

